


ОБОЗНАЧЕНИЕ	D	L	ДИАПАЗОН ЗАЖИМА МЕТЧИКОВ
BT30-12 TCW	36	85	M3-M12
BT40-12 TCW	36	95	M3-M12
BT40-24 TCW	56	140	M12-M24
BT50-12 TCW	36	105	M3-M12
BT50-24 TCW	56	150	M12-M24


РЕЗЬБОВЫЕ ВСТАВКИ




ОБОЗНАЧЕНИЕ	D	L	ДИАПАЗОН ЗАЖИМА МЕТЧИКОВ
G3 TCW	32	19	M3
G4 TCW	32	19	M4
G5 TCW	32	19	M5
G6 TCW	32	19	M6
G8 TCW	32	19	M8
G10 TCW	32	19	M10
G12 TCW	50	31	M12
G14 TCW	50	31	M14
G16 TCW	50	31	M16
G18 TCW	50	31	M18
G20 TCW	50	31	M20
G22 TCW	50	31	M22
G24 TCW	50	31	M24




ОБОЗНАЧЕНИЕ	L	D	M
ER8M-CN	10,8	12	M10x0,75P
ER11M-CN	12	16	M13x0,75P
ER16M-CN	18	22	M19x1,0P
ER20M-CN	19	28	M24X1,0P
ER25M-CN	20	35	M30x1,0P




ОБОЗНАЧЕНИЕ	L	D	M
ER11A-CN	13	19	M14x0,75P
ER16A-CN	18,7	28	M22x1,5P
ER20A-CN	19	34	M25x1,5P




ОБОЗНАЧЕНИЕ	L	D	M
ER25UM-CN	20	42	M32x1,5P
ER32UM-CN	24	50	M40x1,5P
ER40UM-CN	26	63	M50x1,5P
ER50UM-CN	35	78	M64x2,0P




ОБОЗНАЧЕНИЕ	L	D	M
ER11B-CN	13	19	M14x0,75P
ER16B-CN	18,7	28	M22x1,5P
ER20B-CN	19	34	M25x1,5P




ОБОЗНАЧЕНИЕ	L	D	M
ER25GM-CN	20	42	M32x1,5P
ER32GM-CN	24	50	M40x1,5P
ER40GM-CN	26	63	M50x1,5P
ER50GM-CN	35	78	M64x2,0P




ОБОЗНАЧЕНИЕ	A	L
ER11A-CW	35	130
ER16A-CW	44	140
ER20A-CW	53	170




ОБОЗНАЧЕНИЕ	A	L
ER16UM-CW	45	150
ER20UM-CW	55	170
ER25UM-CW	65	210
ER32UM-CW	75	250
ER40UM-CW	90	290
ER50UM-CW	110	350




ОБОЗНАЧЕНИЕ	L	РАЗМЕР	ЗАЖИМНАЯ КРЫШКА
SER25-CW	168	38-42	ER25-B ER25-T2
SER32-CW	190	45-52	ER32-B ER32-T2
SER40-CW	210	55-63	ER40-B ER40-T2
SER50-CW	240	78-85	ER50-B ER50-T2




ОБОЗНАЧЕНИЕ	A	L
ER8M-CW	13	75
ER11M-CW	17	95
ER16M-CW	22,5	118
ER20M-CW	28	130
ER25M-CW	36,5	135



ОБОЗНАЧЕНИЕ	L	D	D1	L2	L3	МАССА (КГ)
BT30-SLN6-50WC	98,4	25	31,8	18		0,66
BT30-SLN6-60WC	108,4	25	31,8	18		0,72
BT30-SLN8-60WC	108,4	28	31,8	18		0,8
BT30-SLN10-60WC	108,4	35	31,8	20		0,83
BT30-SLN12-60WC	108,4	42	31,8	22,5		0,88
BT30-SLN14-60WC	108,4	44	31,8	22,5		1,02
BT30-SLN16-75WC	123,4	48	31,8	24		1,04
BT30-SLN20-75WC	123,4	52	31,8	25		1,36
BT30-SLN25-90WC	138,4	65	31,8	24	25	1,5
BT40-SLN6-50WC	115,4	25	44,5	18		0,96
BT40-SLN8-50WC	115,4	28	44,5	18		1
BT40-SLN10-63WC	128,4	35	44,5	20		1,08
BT40-SLN12-63WC	128,4	42	44,5	22,5		1,2
BT40-SLN14-63WC	128,4	44	44,5	22,5		1,22
BT40-SLN16-63WC	128,4	48	44,5	24		1,24
BT40-SLN20-70WC	135,4	52	44,5	25		2,1
BT40-SLN25-100WC	165,4	65	44,5	24	25	2,08
BT40-SLN32-100WC	165,4	72	44,5	24	28	2,25
BT40-SLN40-120WC	185,4	90	44,5	30	32	2,5
BT50-SLN6-63WC	164,8	25	69,9	18		3,2
BT50-SLN8-63WC	164,8	28	69,9	18		3,23
BT50-SLN10-63WC	164,8	35	69,9	20		3,24
BT50-SLN12-80WC	181,8	42	69,9	22,5		3,36
BT50-SLN16-80WC	181,8	48	69,9	24		3,48
BT50-SLN20-80WC	181,8	52	69,9	25		3,52
BT50-SLN25-100WC	201,8	65	69,9	24	25	4,28
BT50-SLN32-100WC	201,8	72	69,9	24	28	4,44
BT50-SLN40-115WC	216,8	90	69,9	30	32	4,58




ОБОЗНАЧЕНИЕ	D1	L1	L	D	ТИП
C20-ER16A-50WC	20	50	30	28	ER16
C20-ER16A-100WC	20	100	30	28	ER16
C20-ER16A-150WC	20	150	30	28	ER16
C20-ER20A-50WC	20	50	36	34	ER20
C20-ER20A-100WC	20	100	36	34	ER20
C20-ER25-50WC	20	50	46	42	ER25
C20-ER20-100WC	20	100	46	42	ER25
C20-ER25-150WC	20	150	46	42	ER25
C25-ER16-100WC	25	100	30	28	ER16
C25-ER16-150WC	25	150	30	28	ER16
C25-ER20-150WC	25	150	36	34	ER20
C25-ER25-100WC	25	100	46	42	ER25
C25-ER25-150WC	25	150	46	42	ER25
C25-ER32-80WC	25	80	54	50	ER32
C25-ER40-100WC	25	100	55	63	ER40
C32-ER25-60WC	32	60	46	42	ER25
C32-ER32-100WC	32	100	54	50	ER32
C32-ER40-100WC	32	100	55	63	ER40
C40-ER32-100WC	40	100	54	50	ER32
C40-ER40-100WC	40	100	55	63	ER40




ОБОЗНАЧЕНИЕ	D1	L1	L	D	ТИП
C10-ER8M-100WC	10	100	10	12	ER8
C12-ER8M-100WC	12	100	10	12	ER8
C12-ER11M-100WC	12	100	12	16	ER11
C12-ER16M-80WC	12	80	18	22	ER16
C12-ER16M-100WC	12	100	18	22	ER16
C16-ER11M-100WC	16	100	12	16	ER11
C16-ER11M-150WC	16	150	12	16	ER11
C16-ER16M-100WC	16	100	18	22	ER16
C16-ER16M-150WC	16	150	18	22	ER16
C16-ER20M-100WC	16	100	19	28	ER20
C16-ER20M-150WC	16	150	19	28	ER20
C20-ER11M-150WC	20	150	12	16	ER11
C20-ER16M-100WC	20	100	18	22	ER16
C20-ER16M-150WC	20	150	18	22	ER16
C20-ER20M-100WC	20	100	19	28	ER20
C20-ER20M-150WC	20	150	19	28	ER20

ПЕРЕХОДНАЯ ВТУЛКА ДЛЯ ИНСТРУМЕНТА С ЦИЛИНДРИЧЕСКИМ  
ХВОСТОВИКОМ




ПЕРЕХОДНАЯ ВТУЛКА ДЛЯ ИНСТРУМЕНТА С ЦИЛИНДРИЧЕСКИМ  
ХВОСТОВИКОМ




ОБОЗНАЧЕНИЕ	ВНЕШНИЙ ДИАМЕТР (D)	ДЛИНА ЗАЖИМА (L)	ВНУТРЕННИЙ ДИАМЕТР (d)
D16-04	16	40	4
D16-05	16	40	5
D16-06	16	40	6
D16-07	16	40	7
D16-08	16	40	8
D16-09	16	40	9
D16-10	16	40	10
D16-12	16	40	12
D20-04	20	50	4
D20-05	20	50	5
D20-06	20	50	6
D20-07	20	50	7
D20-08	20	50	8
D20-09	20	50	9
D20-10	20	50	10
D20-12	20	50	12
D20-16	20	50	16
D25-06	25	50	6
D25-07	25	50	7
D25-08	25	50	8
D25-09	25	50	9
D25-10	25	50	10
D25-12	25	50	12
D25-14	25	50	14
D25-16	25	50	16
D25-18	25	50	18
D25-20	25	50	20
D32-06	32	60	6
D32-07	32	60	7
D32-08	32	60	8
D32-09	32	60	9
D32-10	32	60	10
D32-12	32	60	12
D32-14	32	60	14

ОБОЗНАЧЕНИЕ	ВНЕШНИЙ ДИАМЕТР (D)	ДЛИНА ЗАЖИМА (L)	ВНУТРЕННИЙ ДИАМЕТР (d)
D32-16	32	60	16
D32-18	32	60	18
D32-20	32	60	20
D32-25	32	60	25
D40-06	40	75	6
D40-07	40	75	7
D40-08	40	75	8
D40-09	40	75	9
D40-10	40	75	10
D40-12	40	75	12
D40-14	40	75	14
D40-16	40	75	16
D40-18	40	75	18
D40-20	40	75	20
D40-25	40	75	25
D40-32	40	75	32
D50-08	50	75	8
D50-10	50	75	10
D50-12	50	75	12
D50-16	50	75	16
D50-20	50	75	20
D50-25	50	75	25
D50-32	50	75	32
D50-40	50	75	40
D60-08	60	75	8
D60-10	60	75	10
D60-12	60	75	12
D60-16	60	75	16
D60-20	60	75	20
D60-25	60	75	25
D60-32	60	75	32
D60-40	60	75	40
D60-50	60	75	50







ОБОЗНАЧЕНИЕ	ВНЕШНИЙ ДИАМЕТР (D)	ДЛИНА ПЕРЕДНЕЙ ЧАСТИ (L1)	ДЛИНА ЗАЖИМА (L2)	ВНУТРЕННИЙ ДИАМЕТР (d)
D20-04AC	20	12	50	4
D20-05AC	20	12	50	5
D20-06AC	20	12	50	6
D20-07AC	20	12	50	7
D20-08AC	20	12	50	8
D20-09AC	20	12	50	9
D20-10AC	20	12	50	10
D20-12AC	20	12	50	12
D20-16AC	20	12	50	16
D25-05AC	25	14	50	5
D25-06AC	25	14	50	6
D25-08AC	25	14	50	8
D25-10AC	25	14	50	10
D25-12AC	25	14	50	12
D25-14AC	25	14	50	14
D25-16AC	25	14	50	16
D25-18AC	25	14	50	18
D25-20AC	25	14	50	20
D32-06AC	32	14	75	6
D32-08AC	32	14	75	8
D32-10AC	32	14	75	10
D32-12AC	32	14	75	12
D32-14AC	32	14	75	14
D32-16AC	32	14	75	16



ОБОЗНАЧЕНИЕ	ВНЕШНИЙ ДИАМЕТР (D)	ДЛИНА ПЕРЕДНЕЙ ЧАСТИ (L1)	ДЛИНА ЗАЖИМА (L2)	ВНУТРЕННИЙ ДИАМЕТР (d)
D32-18AC	32	14	75	18
D32-20AC	32	14	75	20
D32-25AC	32	14	75	25
D40-06AC	40	15	85	6
D40-08AC	40	15	85	8
D40-10AC	40	15	85	10
D40-12AC	40	15	85	12
D40-14AC	40	15	85	14
D40-16AC	40	15	85	16
D40-18AC	40	15	85	18
D40-20AC	40	15	85	20
D40-25AC	40	15	85	25
D40-32AC	40	15	85	32
D50-08AC	50	15	100	8
D50-10AC	50	15	100	10
D50-12AC	50	15	100	12
D50-14AC	50	15	100	14
D50-16AC	50	15	100	16
D50-18AC	50	15	100	18
D50-20AC	50	15	100	20
D50-25AC	50	15	100	25
D50-32AC	50	15	100	32
D50-40AC	50	15	100	40



ОБОЗНАЧЕНИЕ	ВНЕШНИЙ ДИАМЕТР (D1)	ДЛИНА ПЕРЕДНЕЙ ЧАСТИ (l)	ОБЩАЯ ДЛИНА (L)
D20-MT1	20	10	67
D20-MT2	20	15	72
D25-MT1	25	15	75
D25-MT2	25	15	75
D25-MT3	25	15	85
D32-MT1	32	10	75
D32-MT2	32	10	90
D32-MT3	32	10	90
D40-MT1	40	10	75
D40-MT2	40	10	85
D40-MT3	40	10	100
D40-MT4	40	10	120
D50-MT2	50	15	110
D50-MT3	50	15	120
D50-MT4	50	15	150



ОБОЗНАЧЕНИЕ	H	D	H1	L
RD20-16	20	16	38	65
RD25-16	25	16	38	65
RD20-20	20	20	47	65
RD25-20	20	25	47	65
RD20-25	20	25	55	65
RD25-25	25	25	55	65
RD20-32	20	32	55	90
RD25-32	25	32	55	90
RD20-40	20	40	60	90
RD25-40	25	40	60	90
RD25-50	25	50	75	100
RD32-40	32	40	65	100
RD32-50	32	50	75	100

